



Contact (866) 758-3900 for assistance.
Do not return to place of purchase.

Assembly Instructions

Model No. S-1659

Tools Needed

Screwdriver, Wrench

Hardware/Parts

Part	Description	Qty
1	Screen	1
2	Door Knob	2
3	Front Foot	2
4	Back Foot	2
A	Screw	6
B	Nut	6
C	Nut	2
D	Washer	6

Step 1

Attach front and back feet to screen.

Step 2

Attach handles to screen.

CAUTION: Keep this product clean by using a damp cloth. DO NOT use abrasive cleaners, as it will cause parts to tarnish.

